TECHNICAL MANUAL

INSTALLATION MANUAL FOR DOMESTIC UNITS
INSTALLATION MANUAL FOR EXPORT UNITS
SERVICE MANUAL FOR DOMESTIC UNITS

FOR JACKSON MODEL:

WHIRL WIZARD

Jackson
An Enodis Company

January 21, 2004
P/N 7610-011-70-65 (Revision C)

www.jacksonmsc.com

MANUFACTURERS WARRANTY

ONE YEAR LIMITED PARTS & LABOR WARRANTY

ALL NEW JACKSON DISHWASHERS ARE WARRANTED TO THE ORIGINAL PURCHASER TO BE FREE FROM DEFECTS IN MATERIAL OR WORKMANSHIP, UNDER NORMAL USE AND OPERATION FOR A PERIOD OF (1) ONE YEAR FROM THE DATE OF PURCHASE, BUT IN NO EVENT TO EXCEED (18) EIGHTEEN MONTHS FROM THE DATE OF SHIPMENT FROM THE FACTORY.

Jackson MSC agrees under this warranty to repair or replace , at its discretion, any original part which fails under normal use due to faulty material or workmanship during the warranty period, providing the equipment has been unaltered, and has been properly installed, maintained and operated in accordance with the applicable factory instruction manual furnished with the machine and the failure is reported to the authorized service agency within the warranty period. This includes the use of factory specified genuine replacement parts, purchased directly from a Jackson authorized parts distributor or service agency. Use of generic replacement parts may create a hazard and void warranty certification.

The labor to repair or replace such failed part will be paid by Jackson MSC, within the continental United States, Hawaii and Canada, during the warranty period provided a Jackson MSC authorized service agency, or those having prior authorization from the factory, performs the service. Any repair work by persons other than a Jackson MSC authorized service agency is the sole responsibility of the customer. Labor coverage is limited to regular hourly rates, overtime premiums and emergency service charges will not be paid by Jackson MSC.

Accessory components not installed by the factory carry a (1) one year parts warranty only. Accessory components such as table limit switches, pressure regulators, pre rinse units, etc. that are shipped with the unit and installed at the site are included. Labor to repair or replace these components is not covered by Jackson MSC.

This warranty is void if failure is a direct result from shipping, handling, fire, water, accident, misuse, acts of god, attempted repair by unauthorized persons, improper installation, if serial number has been removed or altered, or if unit is used for purpose other than it was originally intended.

TRAVEL LIMITATIONS

Jackson MSC limits warranty travel time to (2) two hours and mileage to (100) one hundred miles. Jackson MSC will not pay for travel time and mileage that exceeds this, or any fees such as those for air or boat travel without prior authorization.

WARRANTY REGISTRATION CARD

The warranty registration card supplied with the machine must be returned to Jackson MSC within 30 days to validate the warranty.

REPLACEMENT PARTS WARRANTY

Jackson replacement parts are warranted for a period of 90 days from the date of installation or 180 days from the date of shipment from the factory, which ever occurs first.

PRODUCT CHANGES AND UPDATES

Jackson MSC reserves the right to make changes in design and specification of any equipment as engineering or necessity requires.

THIS IS THE ENTIRE AND ONLY WARRANTY OF JACKSON MSC. JACKSON'S LIABILITY ON ANY CLAIM OF ANY KIND, INCLUDING NEGLIGENCE, WITH RESPECT TO THE GOODS OR SERVICES COVERED HEREUNDER, SHALL IN NO CASE EXCEED THE PRICE OF THE GOODS OR SERVICES OR PART THEREOF WHICH GIVES RISE TO THE CLAIM.

THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING FOR FITNESS OR MERCHANTABILITY, THAT ARE NOT SET FORTH HEREIN, OR THAT EXTEND BEYOND THE DURATION HEREOF. UNDER NO CIRCUMSTANCES WILL JACKSON MSC BE LIABLE FOR ANY LOSS OR DAMAGE, DIRECT OR CONSEQUENTIAL, OR FOR THE DAMAGES IN THE NATURE OF PENALTIES, ARISING OUT OF THE USE OR INABILITY TO USE ANY OF ITS PRODUCTS.

ITEMS NOT COVERED

This warranty does not cover cleaning or deliming of the unit or any component such as, but not limited to, wash arms, rinse arms or strainers at anytime. Nor does it cover adjustments such as, but not limited to, timer cams, thermostats or doors, beyond 30 days from the date of installation. In addition, the warranty will only cover the replacement of wear items such as curtains, drain balls, door guides or gaskets during the first 30 days after installation. Also not covered are conditions caused by the use of incorrect (non-Commercial) grade detergents, incorrect water temperature or pressure or hard water conditions.

TABLE OF CONTENTS

SECTION	DESCRIPTION	PAGE
I.	**GENERAL**	
	Specifications	1
II.	**INSTRUCTIONS SECTION**	
	Installation Instructions	2
	Installation Assembly	3
	Operation Instructions	4
	Main Assembly	5
	Ordering Replacement Wire	6
	Conduit and Fittings	7
III.	**SCHEMATIC**	
	115 Volt, 60 Hertz, Single Phase	8
	230 Volt, 50-60 Hertz, Single Phase	9
IV.	**Jackson Maintenance and Repair Centers**	10
VI.	**Important Information Data Sheet**	15

SPECIFICATIONS

This unit can be adapted to most standard three compartment sink to provide recirculated water to assist in the removal of soil from ware. The entire unit will fit within the frame work of standard sinks, so no additional floor space is required.

For the 115 Volt unit, a one (1) horsepower motor and pump continually recirculates warm detergent laden water through a unique agitator mounted in the drain hole in the sink. For the 230 Volt unit, a three-quarter (3/4) horsepower motor and pump continually recirculates warm detergent laden water through a unique agitator mounted in the drain hole in the sink. The water exits through vanes located on the agitator causing a vortex in the water in the sink. This constant action, in conjunction with a low sudsing detergent, loosens food soil. A built-in thermostatically controlled heating system maintains water temperature between 110 and 120° Farenheit.

The unit includes the following:

1. For the 115 Volt unit, one (1) horsepower pump motor with built-in thermal overload protection.
   For the 230 Volt unit, a three-quarter (3/4) horsepower motor with built-in thermal overload protection.

2. Pump fitted with internal cutting blades.

3. Built-in thermostatically controlled heating system.

4. Illuminated power ON/OFF switch.

5. Heavy duty grounded power cord.

6. 304 stainless steel construction.

ELECTRICAL REQUIREMENTS:

MODEL	VOLTS	HZ	PHASE	TOTAL AMPS
WW-1	115	60	1	16.1
WW-1	230	50	1	10.2
WW-1	230	60	1	10.2

INSTALLATION INSTRUCTIONS

Jackson MSC Inc. provides technical support for all of the dish-machines detailed in this manual. We strongly recommend that you refer to this manual before making a call to our technical support staff. Please have this manual with you when you call so that our staff can refer you, if necessary, to the proper page. Technical support is available from 8:00 a.m. to 5:00 p.m. (EST), Monday through Friday. Technical support is not available on holidays. Contact technical support toll free at 1-888-800-5672. Please remember that technical support is available for service personnel only.

VISUAL INSPECTION: Before installing the unit, check the container and machine for damage. A damaged container is an indicator that the machine may have been hadled roughly during shipping. If there is damage to both the container and the machine, do not throw away the container. The machine has been inspected at the factory and is expected to arrive to you in new, undamaged condition. However, rough handling by carriers or others may have resulted in damage occuring to the machine. If such a situation does occur, do not return the unit to Jackson. Instead contact both the dealer you purchased the unit through and the carrier. Ask the carrier to send a representative out to inspect the damage and make a report of it. You normally have 48 hours to contact a carrier to report damages, but this varies based on locale. The best advice is to contact your carrier and dealer as soon as damage is discovered.

UNPACKING THE MACHINE: Once the machine has been removed from the container, ensure that there are no obvious missing parts. This may not be apparent at first glance. If you discover that a part is missing, contact Jackson MSC Inc. immediately.

LEVEL THE MACHINE:

1. Position the Whirl Wizard under the sink drainboard.
2. Adjust left to right and front to back.
3. Align inlet and outlet tubes with plumbing from main flow chamber (item 2).
4. To adjust the height, loosen the allen screws in each leg socket connector.
5. Slide leg out to desired height. The drain connection on the machine should be at the same level as the sink drain connection.
6. Tighten the allen head screws in each leg socket connector.
7. Fine adjustments in height can be made by turning the bullet foot in each leg.

INSTALLING THE MACHINE:

1. Locate the sink at the highest end of the drain slope.
2. Disconnect the existing drain plumbing from the sink.
3. Remove the crumb cup.
4. Clean off old plumber's putty from the sink. Add fresh putty to the sink flange.
5. Position the main flow chamber (item 2) through the bottom of the sink. From the bottom, slip the rubber washer (item 3), fiber washer (item 4), back-up flange (item 5) and mounting flange (item 6) on the main flow chamber.
6. Once in position, mount the jam spring (item 7) on to the main flow chamber. This will hold items 3 through 5 in place.
7. Tighten the screws in item 6 until the assembly is held in place. Care must be taken to position screws where they are accessible and will not be covered by the hose barb when assembled into the main flow chamber.
8. In the bottom of the main flow chamber (item 2), install the 1-1/2" NPT close nipple (item 10).
9. The 1-1/2" NPT tee (item 9) is screwed onto the 1-1/2" nipple (item 10).
10. From the tee (item 9) to the drain, install the following items: 1-1/2" close nipple (item 10) and 1-1/2" ball valve (item 11). Make sure the handle of the ball valve (item 11) is easily accessible by the operator.
11. On the sink side of the tee (item 9) install a 1-1/2" NPT hose barb (item 12).
12. On the inlet side of the main flow chamber (item 2) install a 1" NPT hose barb (item 8).
13. With different styles and types of sinks, the directional manifold (item 1) may require modification. The directional tubing may need to be bent to conform to the bottom of the sink or reduced in length. Since it is fabricated from thin wall stainless steel, a hacksaw can be used to cut the tubing.

HOSE CONNECTIONS:

1. Position the 1-1/2" ID intake line hose (item 13) with the Whirl Wizard as xlose to the sink as possible, mark and cut to the length required.
2. Repeat with the 1" ID discharge line hose (item 14).
3. Connect the intake and discharge line hoses with hose clamps (item 15) to their respective connections.

NOTE: ENSURE THAT THE HOSE CLAMPS ARE TIGHT BEFORE OPERATING THE UNIT.

CAUTION: IF DIRECT FLOOR DRAIN IS UNDER OR NEAR MACHINE, MAKE CERTAIN THAT ADEQUATE PROTECTION IS PROVIDED TO PREVENT WATER SPLATTER FROM DAMAGING THE UNIT.

ELECTRICAL POWER CONNECTION:

1. The Whirl Wizard requires a dedicated 20 amp, 115 volt single phase circuit.
2. A 20 amp NEMA 5-20R receptacle is required for the NEMA 5-20P cord set and plug shipped with the machine.

CAUTION: A NEMA 5-20R RECEPTACLE IS REQUIRED. IF NOT AVAILABLE A QUALIFIED ELECTRICIAN SHOULD INSTALL THE CORRECT RECEPTACLE.

INSTALLATION ASSEMBLY



ITEM	QTY	DESCRIPTION	Mfg. No.
1	1	Directional Manifold	5700-031-70-49
2	1	Main Flow Chamber	5700-031-83-05
3	1	Rubber Washer, 3-1/2" Diameter	5330-011-70-87
4	1	Fiber Washer, 3-1/2" Diameter	5330-011-70-48
5	1	Flange, Back-Up	5340-011-83-13
6	1	Mounting Flange	5340-011-83-14
7	1	Spring, Jam	5340-011-83-04
8	1	Hose Barb, 1" NPT to 1" Hose Brass	4730-011-70-36
9	1	Tee, 1-1/2" FNPT, Brass	4730-011-70-39
10	2	Nipple, Close, 1-1/2" NPT, Stainless Steel	4730-011-70-86
11	1	Ball Valve Assembly	5700-011-70-40
		Ball Valve Only	4820-111-71-46
		Handle Only	5700-021-84-75
12	1	Hose Barb, 1-1/2" NPT x 1-1/2" PVC	4730-011-70-38
13	1	Hose, 1-1/2" ID x 2'-0" Long	5700-021-69-20
14	1	Hose, 1" ID x 12" Long	5700-021-69-19
15	4	Hose Clamp, 1 5/16" - 2 1/4"	4730-719-01-37

OPERATION INSTRUCTIONS

OPERATION:

1. Install the directional manifold (item 1) into the main flow chamber (item 2).

2. Fill the sink with hot water.

3. Add the proper chemicals (non-foaming detergent) for soaking pots, pans and utensils.

4. Pre-scrap pots, pans and utensils of all large loose soil.

NOTE: THE WHIRL WIZARD POT SINK IS NOT A GARBAGE DISPOSAL! IT IS INTENDED TO SOFTEN SOIL WHICH IS DIFFICULT TO REMOVE. BAKED-ON SOIL MAY STILL REQUIRE ADDITIONAL EFFORT TO REMOVE.

5. With the power switch in the ON position, place the soiled pots, pans and utensils into the sink.

NOTES: PLACEMENT OF POTS AND PANS SHOULD BE DONE IN A MANNER THAT NOTHING WILL OBSTRUCT THE MAIN FLOW OF WATER.

6. Allow pots, pans and utensils to soak for 15 to 20 minutes to soften and loosen soil.

CLEANING INSTRUCTIONS:

1. Turn the power switch to the OFF position.

2. Turn the ball valve to the open position and drain the sink.

3. When the sink is empty, remove the directional manifold (rotate counter-clockwise) and clean.

4. Re-install the directional manifold into the main flow chamber.

CHANGING DIRECTION OF MACHINE INSTALLATION:

1. Remove the cover from the Whirl Wizard.

2. Remove the power switch from the side and insert into the pre-punched hole in the opposite end of the unit.

3. To extend the wiring, cut the tie wraps. There is sufficient length to allow the power switch to be relocated.

4. Re-install the cover.

MAIN ASSEMBLY



ITEM	QTY	DESCRIPTION	Mfg. No.
1	1	Cover Weldment	5700-021-67-90
2	1	Box Bottom	5700-031-67-89
3	2	Screw, 10-32 x 1/2" Long, Truss Head	5305-011-39-36
4	4	Leg Weldment	5700-021-67-92
5	4	Bullet Foot	5340-108-01-03
6	1	Pump and Motor Assembly, 1 HP	6105-021-69-18
6	1	Pump and Motor Assembly, 3/4 HP	6105-002-33-78
7	1	Chopper Assembly	5700-021-70-32
8	4	Locknut, 1/4"-20 with Nylon Insert	5310-374-01-00
9	4	Flat Washer, 1/4"	5311-174-01-00
10	1	Inlet Plumbing	5700-031-68-31
11	1	"J" Tube, Outlet	5700-021-68-60
12	1	Suction Connector Tube	5700-011-70-33
13	1	Discharge Connector Tube	5700-011-70-34
14	4	Hose Clamp, 2"	4730-719-01-37
15	1	Heater, Flexible, 120 Volts, 400 Watts	4540-021-70-21
16	1	Contactor, Motor	5945-109-05-69
17	1	Power Switch	5930-011-82-72
18	1	Power Cord	6145-011-70-28
19	1	Decal Whirl Wizard Logo, Left	9905-021-70-64
20	1	Decal, Whirl Wizard Logo, Right (Not Shown)	9905-021-70-59

ORDERING REPLACEMENT WIRE

ORDERING REPLACEMENT WIRE FOR YOUR DISHMACHINE

Jackson products have several color and gauges of wire used in them and it may become necessary to replace these wires. Wire may be ordered from Jackson MSC Inc., but please note that it is only available in feet. Ensure that you order the correct color and guage.

BLACK WIRE:

6 Gauge	6145-002-15-91
8 Gauge	6145-104-43-00
10 Gauge	6145-104-16-00
12 Gauge	6145-112-01-00
14 Gauge	6145-104-09-00
18 Gauge	6145-104-01-97
18 Gauge with Orange Stripes	6145-011-35-66
18 Gauge with White Stripes	6145-011-35-65
18 Gauge with Yellow Stripes	6145-011-35-64

BLUE WIRE:

6 Gauge	6145-002-15-93
8 Gauge	6145-104-44-00
10 Gauge	6145-104-42-00
14 Gauge	6145-104-04-00
18 Gauge	6145-104-35-00
18 Gauge with Black Stripes	6145-011-46-35
18 Gauge with Red Stripes	6145-011-46-37
18 Gauge with White Stripes	6145-011-46-36
18 Gauge with Yellow Stripes	6145-011-46-38
20 Gauge	6145-104-06-97
20 Gauge with Black Stripes	6145-104-17-97
20 Gauge with White Stripes	6145-104-13-97

GREEN WIRE:

8 Gauge	6145-002-15-94
14 Gauge	6145-104-03-00
18 Gauge	6145-104-32-00
18 Gauge with Yellow Stripes	6145-001-44-96
20 Gauge	6145-104-05-97
20 Gauge with Black Stripes	6145-011-59-57
20 Gauge with Yellow Stripes	6145-104-11-97

GREY WIRE:

18 Gauge	6145-104-36-00
18 Gauge with Black Stripes	6145-011-81-71
18 Gauge with Blue Stripes	6145-011-81-72
18 Gauge with Red Stripes	6145-011-46-41
18 Gauge with White Stripes	6145-011-35-60
18 Gauge with Yellow Stripes	6145-011-46-42
20 Gauge	6145-104-03-97

RED WIRE:

6 Gauge	6145-002-15-92
8 Gauge	6145-104-45-00
10 Gauge	6145-104-08-00
14 Gauge	6145-104-05-00
18 Gauge	6145-104-37-00
18 Gauge with Black Stripes	6145-011-59-56
18 Gauge with Blue Stripes	6145-011-81-74
18 Gauge with White Stripes	6145-011-81-73
18 Gauge with Yellow Stripes	6145-011-81-75
20 Gauge	6145-104-02-97

WHITE WIRE:

10 Gauge	6145-104-19-00
14 Gauge	6145-104-10-00
18 Gauge	6145-104-39-00
18 Gauge with Black Stripes	6145-011-35-70
18 Gauge with Blue Stripes	6145-011-46-40
18 Gauge with Green Stripes	6145-011-35-69
18 Gauge with Grey Stripes	6145-002-20-18
18 Gauge with Red Stripes	6145-011-35-67
18 Gauge with Yellow Stripes	6145-011-35-68
20 Gauge	6145-104-04-97
20 Gauge with Orange & Yellow Stripes	6145-104-16-97
20 Gauge with Yellow Stripes	6145-104-15-97

YELLOW WIRE:

18 Gauge	6145-104-33-00
18 Gauge with Black Stripes	6145-011-81-68
18 Gauge with Blue Stripes	6145-011-81-70
18 Gauge with Red Stripes	6145-011-81-69
20 Gauge	6145-104-07-97

ORDERING REPLACEMENT WIRE (CONTINUED)/CONDUIT & FITTINGS

MISCELLANEOUS WIRE:

Brown (18 Gauge)	6145-104-20-00
Brown (20 Gauge)	6145-104-08-97
Orange (18 Gauge)	6145-104-34-00
Orange with Black Stripes (18 Gauge)	6145-011-35-62
Orange with Blue Stripes (18 Gauge)	6145-011-46-39
Orange with White Stripes (18 Gauge)	6145-011-35-63
Orange with Yellow Stripes (18 Gauge)	6145-011-35-61
Orange (20 Gauge)	6145-104-10-97
Pink (18 Gauge)	6145-011-82-69
Purple (18 Gauge)	6145-104-31-00
Violet (20 Gauge)	6145-104-09-97
Plug, GFI	6145-001-97-90
Cable, 16 Gauge, 3 Wire Romex	6145-001-98-29
Cord, Hubble Plug MC	6145-011-47-23
Cord, S-J	6145-011-49-02
Cord, Power	6145-011-70-28
Cord, 115V Power	6145-309-02-00
Cord, 125V Power, 96 " Long	6145-309-04-00

CONDUIT AND RELATED FITTINGS

Jackson products come with a wide variety of conduit and fittings for use in routing the wires of the machine. The list below provides for most of stock of such items. When ordering, remember that Jackson does not offer pre-cut sections of conduit for your machine, instead it is sold by the foot. Please take into account in slack that will be necessary once installing the new conduit to ensure that it fits correctly. It is recommended that you order at least 6" more conduit than you require to ensure that you have enough for trimming.

CONDUIT:

Conduit, 1/2", Liquidtite	5975-101-25-00
Conduit, 1/2", Non-Metallic	5975-111-46-57
Conduit, 1/2", PVC	5975-105-04-00
Conduit, 1/2", Sealtite	5975-105-01-00
Conduit, 1/2", Xtraflex	5975-105-06-44
Conduit, 3/8", Liquidtite	5975-105-02-00
Conduit, 3/4", Cole-Flex	5975-105-05-00
Conduit, 3/4", Liquidtite	5975-105-03-00
Conduit, 3/4", Non-Metallic	5975-011-47-71
Conduit, 3/4" Xtraflex	5975-105-07-44
Conduit, 1", Carlon	5975-011-68-42

CONDUIT FITTINGS:

Elbow, Cole-Flex, 1/2", 90 Degree	5975-205-40-00
Elbow, Xtraflex, 1/2", 90 Degree	5975-205-44-44
Elbow, Xtraflex, 3/4", 90 Degree	5975-205-45-44
Fitting, 1/2" Straight	5975-011-45-13
Fitting, 1/2", Straight, Zinc Plated	5975-111-89-89
Fitting, 1/2", 45 Degree	5975-011-45-23
Fitting, 1/2", 45 Degree, Zinc Plated	5975-111-89-86
Fitting, 1/2", 90 Degree	5975-011-45-14
Fitting, 1/2", 90 Degree, Zinc Plated	5975-111-89-88
Fitting, 3/4", Straight	5975-011-47-72
Fitting, 3/4", 45 Degree	5975-011-47-74
Fitting, 3/4", 90 Degree	5975-011-47-73
Fitting, 1", Straight	5975-011-70-75
Fitting, 1", 90 Degree	5975-011-68-43
Fitting, Cole-Flex, 1/2" Straight	5975-205-03-00
Fitting, Cole-Flex, 3/4" Straight	5975-205-41-00
Fitting, Cole-Flex, 3/4", 90 Degree	5975-204-42-00
Fitting, Liquidtite, .231 ID/.394 OD	5975-011-49-03
Fitting, Liquidtite, .25 ID/.546 OD	5975-011-65-51
Fitting, Liquidtite, .27 ID/.48 OD	5975-011-59-50
Fitting, Liquidtite, 1/2", 90 Degree	5975-111-01-00
Fitting, Liquidtite, 3/8", Straight	5975-205-03-82
Fitting, Liquidtite, 3/8", 90 Degree	5975-205-02-82
Fitting, Liquidtite, 3/4", Straight	5975-205-15-02
Fitting, Liquidtite, 3/4", 45 Degree	5975-205-01-82
Fitting, Liquidtite, 3/4", 90 Degree	5975-205-07-82
Fitting, Xtraflex, 1/2", Straight	5975-205-47-44
Fitting, Xtraflex, 3/4", Straight	5975-205-46-44
Nut, 1-1/4"	5975-011-42-54

WHIRL WIZARD
ELECTRICAL DIAGRAM
115 VOLT - 60 HERTZ - SINGLE PHASE



9905-011-70-30

SEQUENCE OF OPERATION

1. After the sink is filled with water, power switch (S1) is placed in the “ON” position.

2. Motor contactor (R1) is energized.

3. Pump motor (M1) starts.

4. Heater element (H1) is energized.

5. Power light (E1) is energized.

NOTE: THE HEATER ELEMENT CONTAINS AN INTERNALLY-MOUNTED THERMOSTAT TO REGULATE THE TEMPERATURE OF THE ELEMENT.

WHIRL WIZARD
ELECTRICAL DIAGRAM
240 VOLT - 50/60 HERTZ - SINGLE PHASE



LEGEND

H1 HEATER
R1 MOTOR AND HEATER CONTACTOR
M1 PUMP MOTOR
S1 POWER SWITCH
E1 POWER LIGHT
T1 TRANSFORMER

9905-002-33-80

SEQUENCE OF OPERATION

1. After the sink is filled with water, power switch (S1) is placed in the “ON” position.

2. Motor contactor (R1) is energized.

3. Pump motor (M1) starts.

4. Heater element (H1) is energized.

5. Power light (E1) is energized.

NOTE: THE HEATER ELEMENT CONTAINS AN INTERNALLY-MOUNTED THERMOSTAT TO REGULATE THE TEMPERATURE OF THE ELEMENT.

JACKSON MAINTENANCE & REPAIR CENTERS

ALABAMA:

JONES-McLEOD APPLIANCE SVC
1616 7TH AVE. NORTH
BIRMINGHAM, AL 35203
(205) 251-0159
800-821-1150
FAX: (205) 322-1440
service@jones-mcleod.com

JONES-McLEOD APPLIANCE SVC
854 LAKESIDE DRIVE
MOBILE, AL 36693
(334) 666-7278
800-237-9859
FAX: (334) 661-0223

ALASKA:

RESTAURANT APPLIANCE SVC
7219 ROOSEVELT WAY NE
SEATTLE, WA 98115
(206) 524-8200
800-433-9390
FAX: (206) 525-2890
info@restappl.com

ARIZONA:

AUTHORIZED COMMERCIAL FOOD EQMT. SVC
4832 SOUTH 35TH STREET
PHOENIX, AZ 85040
(602) 234-2443
800-824-8875
FAX: (602) 232-5862
acsboss@aol.com

GCS SERVICE INC. #78
5052 SOUTH 40TH STREET
PHOENIX, AZ 85040
(602) 474-4510
800-510-3497
FAX: (602) 470-4511
phoenix@gcssvc.com

ARKANSAS:

BROMLEY PARTS & SVC
10TH AND RINGO
P.O. BOX 1688
LITTLE ROCK, AR 72202
(501) 374-0281
800-482-9269
FAX: (501) 374-8352
brom@mindspring.com

COMMERCIAL PARTS & SVC.
3717 CHERRY ROAD
MEMPHIS, TN 38118
(901) 366-4587
800-262-9155
FAX: (901) 366-4588

CALIFORNIA:

BARKERS FOOD MACHINERY SERVICES
5367 SECOND STREET
IRWINDALE, CA 91706
(626) 960-9390
800-258-6999
FAX: (626) 337-4541
service@barkers.com

GCS SERVICE INC. #24
1100 EAST PICO BLVD.
LOS ANGELES, CA 90021
(213) 683-2090
800-327-1433
FAX: (213) 683-2099
los_angeles@gcssvc.com

GCS SERVICE INC. #24
650 S. GRAND AVE. STE 111
SANTA ANA, CA 92705
(714) 542-1798
800-540-0719
FAX: (714) 542-4787
santa_ana@gcssvc.com

GCS SERVICE INC. #52
360 LITTLEFIELD
S. SAN FRANCISCO, CA 94080
(650) 635-0720
800-969-4427
FAX: (650) 871-4019
san_francisco@gcssvc.com

GCS SERVICE INC. #84
9030 KENAMAR DR. STE 313
SAN DIEGO, CA 92121
(858) 549-8411
800-422-7278
FAX: (858) 549-2323
san_diego@gcssvc.com

P & D APPLIANCE SVC
100 SOUTH LINDEN AVE.
S. SAN FRANCISCO, CA 94080
(650) 635-1900
800-424-1414
FAX: (650) 635-1919
pndappl@aol.com

P & D APPLIANCE
4220-C ROSEVILLE ROAD
NORTH HIGHLANDS, CA 95660
(916) 974-2772
800-824-7219
FAX:(916) 974-2774

COLORADO:

GCS SERVICE INC.
4251 S. NATCHES CT. #60#
UNIT C
SHERIDAN, CO 80110
(303) 371-9054
800-972-5314
FAX: (303) 371-4754
denver@gcssvc.com

METRO APPLIANCE SERVICE
1640 S BROADWAY
DENVER, CO 80210
(303) 778-1126
800-525-3532
FAX: (303) 778-0268
metroappls@aol.com

CONNECTICUT:

GCS SERVICE INC. #06
302 MURPHY ROAD
HARTFORD, CT 06114
(860) 549-5575
800-423-1562
FAX: (860) 527-6355
hartford@gcssvc.com

DELAWARE:

FOOD SERVICE EQMT.
2101 PARKWAY SOUTH
BROOMALL, PA 19008
(610) 356-6900
FAX: (610) 356-2038
dancerule@aol.com

GCS SERVICE INC. #44
817 N THIRD STREET
P.O. BOX 3564
PHILADELPHIA, PA 19123
(215)925-6217
800-441-9115
FAX: (215) 925-6208
philadelphia@gcssvc.com

ELMER SCHULTZ SERVICE
36 BELMONT AVE.
WILLMINGTON, DE 19804
(302) 655-8900
800-225-0599
FAX: (302) 656-3673
elmer2@erols.com

EMR SERVICE DIVISION
106 WILLIAMSPORT CIRCLE
SALISBURY, MD 21804
(410) 543-8197
FAX: (410) 548-4038

FLORIDA:

COMMERCIAL APPLIANCE SVC
8416 LAUREL FAIR CIRCLE
BLDG 6, SUITE 114
TAMPA, FL 33610
(813) 663-0313
800-282-4718
FAX: (813) 663-0212
commercialappliance@worldnet.att.net

GCS SERVICE INC #15
3373 NW 168TH ST.
MIAMI, FL 33056
(305) 621-6666
800-766-8966
FAX: (305) 621-6656
miami@gcssvc.com

GCS SERVICE INC #13
4305 VINELAND RD STE G-12
ORLANDO, FL 32811
(407) 841-2551
800-338-7322
FAX: (407) 423-8425
orlando@gcssvc.com

GCS SERVICE INC #14
3902 CORPOREX PARK DR.
SUITE 350
TAMPA, FL 33619
(813) 626-6044
800-282-3008
FAX: (813) 621-1174
tampa@gcssvc.com

JONES-McLEOD APPLIANCE SVC
854 LAKESIDE DRIVE
MOBILE, AL 36693
(334) 666-7278
800-237-9859
FAX: (334) 661-0223
service@jones-mcleod.com

GEORGIA:

GCS SERVICE INC #16
3127 PRESIDENTIAL DR.
ATLANTA, GA 30340
(770) 452-7322
800-334-3599
FAX: (770) 452-7473
atlanta@gcssvc.com

SOUTHEASTERN RESTAURANT SVC.
2200 NORCROSS PKWY. SUITE 210
NORCROSS, GA 30071
(770) 446-6177
800-235-6516
FAX: (770) 446-3157
info@srs-atl.com

WHALEY FOODSERVICE REPAIRS
109-A OWENS INDUSTRIAL DRIVE
SAVANNAH, GA 31405
(912) 447-0827
888-765-0036
FAX: (912) 447-0826

HAWAII:

FOOD EQMT. PARTS & SERVICE CO.
300 PUUHALE RD.
HONOLULU, HI 96819
(808) 847-4871
FAX: (808) 842-1560
fepsco@hula.net

JACKSON MAINTENANCE & REPAIR CENTERS

IDAHO:

RESTAURANT APPLIANCE SVC.
7219 ROOSEVELT WAY NE
SEATTLE, WA 98115
(206) 524-8200
800-433-9390
FAX: (206) 525-2890
info@restappl.com

RON'S SERVICE
703 E 44TH STREET STE 10
GARDEN CITY, ID 83714
(208) 375-4073
FAX: (208) 375-4402

ILLINOIS:

CONES REPAIR SVC.
2408 40TH AVE.
MOLINE, IL 61265
(309) 797-5323
800-716-7070
FAX: (309)797-3631
jackb@cones.com

EICHENAUER SERVICES INC.
130 S OAKLAND ST.
DECATUR, IL 62522
(217) 429-4229
800-252-5892
FAX: (217) 429-0226
esi@esiquality.com

GCS SERVICE INC. #12
696 LARCH AVE.
ELMHURST, IL 60126
(630) 941-7800
800-942-9689
FAX: (630) 941-6048
chicago@gcsscv.com

GCS SERVICE INC. #80
9722 REAVIS PARK DR.
ST. LOUIS, MO 63123
(314) 683-7444
800-284-4427
FAX: (314) 638-0135
st_louis@gcssvc.com

INDIANA:

COMMERCIAL PARTS & SERVICE
5310 E 25TH STREET
INDIANAPOLIS, IN 46218
(317) 545-9655
800-727-8710
FAX: (317) 549-6286
peproane@aol.com

IOWA:

GOODWIN-TUCKER GROUP
3509 DELAWARE AVENUE
DES MOINES, IA 50313
(515) 262-9308
800-372-6066
FAX: (515) 262-2936
goodwintuc@aol.com

CONES REPAIR SVC.
1056 27TH AVENUE SW
CEDAR RAPIDS, IA 52404
(319) 365-3325
800-747-3326
FAX: (319) 365-0885

KANSAS:

GCS SERVICE INC. #82
6107 CONNECTICUT
KANSAS CITY, MO 64120
(816) 920-5999
800-229-6477
FAX: (816) 920-7387
kansas_city@gcssvc.com

KENTUCKY:

CERTIFIED SERVICE CENTER
RAMCO BUSINESS PARK
4283 PRODUCE ROAD
LOUISVILLE, KY 40218
(502) 964-7007
800-637-6350
FAX: (502) 964-7202
droenigk@certifiedsc.com

CERTIFIED SERVICE CENTER
1051 GOODWIN DRIVE
LEXINGTON, KY 40505
(606) 254-8854
800-432-9269
FAX: (606) 231-7781
jatkins@certifiedsc.com

COMMERCIAL PARTS & SERVICE
4204 SOUTH BROOK STREET
LOUISVILLE, KY 40214
(502) 367-1788
800-752-6160
FAX: (502) 367-0400

COMMERCIAL PARTS & SERVICE
1002 NANDINO BLVD.
LEXINGTON, KY 40511
(606) 255-0746
800-432-9260
FAX: (606) 255-0748

LOUISIANA:

BANA PARTS INC.
1501 KUEBLE STREET
HARAHAN, LA 70123
(504) 734-0076
800-325-7543
FAX: (504) 734-8456

BANA PARTS INC.
4028 GREENWOOD ROAD
SHREVEPORT, LA 71109
(318) 631-6550
800-832-6550
FAX: (318) 636-5675

MAINE:

GCS SERVICE INC. #09
180 SECOND STREET
CHELSEA, MA 02150
(617) 889-9393
800-225-1155
FAX: (617) 889-1222
boston@gcssvc.com

MASSACHUSETTS RESTAURANT SUPPLY
34 SOUTH STREET
SOMERVILLE, MA 02143
(617) 868-1930
800-338-6737
FAX: (617) 686-5331

NORTHERN CROWN SERVICES, INC.
225 INDUSTRIAL WAY
PORTLAND, ME 04103
(207) 797-7333
(800) 696-7560
FAX: (207) 696-1128
steve@northerncrownservices.com
or
richard@northerncrownservices.com

MARYLAND:

EMR SERVICE DIVISION
700 EAST 25TH STREET
BALTIMORE, MD 21218
(410) 467-8080
800-879-4994
FAX: (410) 467-4191
baltparts@emrco.com

EMR SERVICE DIVISION
106 WILLIAMSPORT CIRCLE
SALISBURY, MD 21804
(410) 543-8197
888-687-8080
FAX: (410) 548-4038
baltparts@emrco.com

EMR SERVICE DIVISION
2626 PITTMAN DRIVE
SILVER SPRING, MD 20910
(301) 588-8080
800-348-2365
FAX: (301) 588-6985
baltparts@emrco.com

GCS SERVICE INC. #07
2660 PITTMAN DRIVE
SILVER SPRING, MD 20910
(301) 585-7550 (DC)
(410) 792-0338 (BALT)
(800) 638-7278
FAX: (301) 495-4410
dc_baltimore@gcssvc.com

MASSACHUSETTS:

ACE SERVICE CO.
95 HAMPTON AVE.
NEEDHAM, MA 02494
(781) 449-4220
800-225-4510 MA & NH
FAX: (781) 444-4789
taceservice@aol.com

MASSACHUSETTS RESTAURANT SUPPLY
34 SOUTH STREET
SOMERVILLE, MA 02143
(617) 868-1930
800-338-6737
FAX: (617) 868-5331

GCS SERVICE INC. #09
180 SECOND STREET
CHELSEA, MA 02150
(617) 889-9393
800-225-1155
FAX: (617) 889-1222
boston@gcssvc.com

GCS SERVICE INC. #06
302 MURPHY ROAD
HARTFORD, CT 06114
(860) 549-5575
800-723-1562
FAX: (860) 527-6355
hartford@gcssvc.com

MICHIGAN:

GCS SERVICE INC. #20
31829 WEST EIGHT MILE RD.
LIVONIA, MI 48152
(248) 426-9500
800-772-2936
FAX: (248) 426-7555
detroit@gcssvc.com

JACKSON SERVICE COMPANY
3980 BENSTEIN RD.
COMMERCE TWSHP, MI 48382
(248) 363-4159
800-332-4053
FAX: (248) 363-5448

GCS SERVICE INC. #21
3516 ROGER B. CHAFFE SE
GRAND RAPIDS, MI 49548
(616) 241-0200
800-823-4866
FAX: (616) 241-0541
grand_rapids@gcssvc.com

MINNESOTA:

GCS SERVICE INC.
2857 LOUISIANA AVENUE N.
MINNEAPOLIS, MN 55427
(612) 546-4221
800-345-4221
FAX: (612) 546-4286
minneapolis@gcssvc.com

JACKSON MAINTENANCE & REPAIR CENTERS

MISSISSIPPI:

COMMERCIAL PARTS & SVC.
5755 GALLANT DRIVE
JACKSON, MS 39206
(601) 956-7800
800-274-5954
FAX: (601) 956-1200

COMMERCIAL PARTS & SVC.
3717 CHERRY ROAD
MEMPHIS, TN 38118
(901) 366-4587
800-262-9155
FAX: (901) 366-4588

MISSOURI:

GCS SERVICE INC. #82
6107 CONNECTICUT
KANSAS CITY, MO 64120
(816) 920-5999
800-229-6477
FAX: (816) 920-7387
kansas_city@gcssvc.com

GCS SERVICE INC. #80
9722 REAVIS PARK DR.
ST. LOUIS, MO 63123
(314) 638-7444
800-284-4427
FAX: (314) 638-0135
st_louis@gcssvc.com

KAMMERLIN PARTS & SVC.
2728 LOCUST STREET
ST. LOUIS, MO 63103
(314) 535-2222
FAX: (314) 535-6205

MONTANA:

RESTAURANT APPLIANCE SVC.
7219 ROOSEVELT WAY NE
SEATTLE, WA 98115
(206) 524-8200
800-433-9390
FAX: (206) 525-2890
info@restappl.com

NEBRASKA:

GOODWIN - TUCKER GROUP
815 N 19TH STREET
OMAHA, NE 68102
(402) 345-7400
800-228-0342
FAX: (402) 346-6145
goodwintuc@aol.com

NEVADA:

BURNEY'S COMMERCIAL SVC
4480 ALDEBARAN AVE.
LAS VEGAS, NV 89103
(702) 736-0006
FAX: (702) 798-7531

GCS SERVICE INC. #77
3585 EAST PATRICK LANE
SUITE 1000
LAS VEGAS, NV 89102
(702) 450-3495
800-500-9060
FAX: (702) 450-3491
las_vegas@gcssvc.com

NEW HAMPSHIRE:

GCS SERVICE INC. #09
180 SECOND STREET
CHELSEA, MA 02150
(617)889-9393
800-225-1155
FAX: (617) 889-1222
boston@gcssvc.com

ACE SERVICE CO.
95 HAMPTON AVE.
NEEDHAM, MA 02494
(781) 449-4220
800-225-4510 MA & NH
FAX: (781) 444-4789
taceservice@aol.com

MASSACHUSETTS RESTAURANT SUPPLY
34 SOUTH STREET
SOMERVILLE, MA 02143
(617) 868-1930
800-338-6737
FAX: (617) 868-5331

NEW JERSEY:

JACKSON FASPRAY SVC.
155 SARGEANT AVE.
CLIFTON, NJ 07013
(973) 471-8000
800-356-6740
FAX: (973) 471-1289

GCS SERVICE INC. #2
1 MADISON STREET
BUILDING F
EAST RUTHERFORD, NJ 07073
(973) 614-0003
800-399-8294
FAX: (973) 614-0230
east_rutherford@gcssvc.com

GCS SERVICE INC. #44
817 N THIRD STREET
PHILADELPHIA, PA 19123
(215) 925-6217
800-441-9115
FAX: (215) 925-6208

ELMER SCHULTZ SERVICES
201 W. WASHINGTON AVE.
PLEASANTVILLE, NJ 08232
(609) 641-0317
800-378-1641
FAX:(609) 641-8703
philadelphia@gcssvc.com

FOOD SERVICE EQMT.
2101 PARKWAY SOUTH
BROOMALL, PA 19008
(610) 356-6900
FAX: (610) 356-2038
dancerule@aol.com

NEW MEXICO:

STOVE PARTS SUPPLY CO.
2120 SOLANA STREET
FORT WORTH, TX 76117
(817) 831-0381
800-433-1804
FAX: (817) 834-7754
bua@stoveparts.com

NEW YORK:

APPLIANCE INSTALLATION AND SERVICE CORP.
1336 MAIN STREET
BUFFALO, NY 14209
(716) 884-7425
800-722-1252
FAX: (716) 884-0410
ais@worldnet.att.net

B.E.S.T. INC.
3003 GENESEE STREET
BUFFALO, NY 14225
(716) 893-6464
800-338-5011
FAX: (716) 893-6466
bestserv@aol.com

DUFFY'S EQUIPMENT SVC.
3138 ONEIDA STREET
SAUQUOIT, NY 13456
(315) 737-9401
800-443-8339
FAX: (315) 737-7132
duffyequip@aol.com

NORTHERN PARTS & SVC.
21 NORTHERN AVENUE
PLATTSBURGH, NY 12903
(518) 563-3200
800-634-5005
FAX: (800) 782-5424
info@northernparts.com

GCS SERVICE INC. #01
932 GRAND STREET
BROOKLYN, NY 11211
(718) 486-5220
800-969-4271
FAX: (718) 486-6772
new_york@gcssvc.com

JACKSON FASPRAY SVC.
155 SARGEANT AVE.
CLIFTON, NJ 07013
(973) 471-8000
800-356-6740
FAX: (973) 471-1289
jfs155@aol.com

NORTH CAROLINA:

WHALEY FOODSERVICE
8334-K ARROWRIDGE BLVD
CHARLOTTE, NC 28273
(704) 529-6242
FAX: (704) 529-1558
info@whaleyfoodservice.com

WHALEY FOODSERVICE REPAIRS
203-D CREEK RIDGE RD.
GREENSBORO, NC 27406
(336) 333-2333
FAX: (336) 333-2533
info@whaleyfoodservice.com

WHALEY FOODSERVICE REPAIRS
335-105 SHERWEE DRIVE
RALEIGH, NC 27603
(919) 779-2266
FAX: (919) 779-2224
info@whaleyfoodservice.com

WHALEY FOODSERVICE REPAIRS
6418-101 AMSTERDAM WAY
WILMINGTON, NC 28405
(910) 791-0000
FAX: (910) 791-6662
info@whaleyfoodservice.com

NORTH DAKOTA:

METRO COMMERCIAL SERVICE INC.
2857 LOUISIANA AVENUE N.
MINNEAPOLIS, MN 55427
(612) 546-4221
800-345-4221
FAX: (612) 546-4286
minneapolis@gcssvc.com

OHIO:

CERTIFIED SERVICE CENTER
890 REDNA TERRACE
CINCINNATI, OH 45215
(513) 772-6600
800-543-2060
FAX: (513) 612-6600
sbarasch@certifiedsc.com

COMMERCIAL PARTS & SVC.
OF COLUMBUS
1150 WEST MOUND STREET
COLUMBUS, OH 43223
(614) 221-0057
800-837-8327
FAX: (614) 221-3622

GCS SERVICE INC.
2830 JOHNSTOWN ROAD
COLUMBUS, OH 43219
(614) 476-3225
800-282-5406
FAX: (614) 476-1196
columbus@gcssvc.com

JACKSON MAINTENANCE & REPAIR CENTERS

ELECTRICAL APPLIANCE REPAIR SVC.
5805 VALLEY BELT ROAD
CLEVELAND, OH 44131
(216) 459-8700
800-621-8259
FAX: (216) 459-8707
tomr@electapplrep.com

OKLAHOMA:

HAGAR RESTAURANT EQMT.
1229 W MAIN STREET
OKLAHOMA CITY, OK 73106
(405) 235-2184
800-445-1791
FAX: (405) 236-5592

KRUEGER INC.
100 NE 24TH STREET
OKLAHOMA CITY, OK 73105
(405) 528-8883
800-522-8069
FAX: (405) 528-5405
kruegers@swbell.net

OREGON:

RON'S SERVICE
16364 SW 72ND AVE
PORTLAND, OR 97224
(503) 624-0890
800-851-4118
FAX: (503) 684-6107
lrobinson@ronsservice.com

PENNSYLVANIA:

A.I.S. COMMERCIAL PARTS & SERVICE
1816 WEST 26TH STREET
ERIE, PA 16508
(814) 456-3732
800-332-3732
FAX: (814) 452-4843
aiserie@aol.com

AFS-AUTHORIZED FACTORY SVC. INC.
940 FIRST AVE.
CORAOPOLIS, PA 15108
(412) 262-2330
800-222-8767
FAX: (412) 262-2245

ELMER SCHULTZ SVC.
540 NORTH 3RD STREET
PHILADELPHIA, PA 19123
(215) 627-5400
FAX: (215) 627-5408
elmer2@erols.com

FOOD SERVICE EQMT.
2101 PARKWAY SOUTH
BROOMALL, PA 19008
(610) 356-6900
FAX: (610) 356-2038
dancerule@aol.com

GCS SERVICE INC. #44
817 N THIRD STREET
P.O. BOX 3564
PHILADELPHIA, PA 19123
(215) 925-6217
800-441-9115
FAX: (215) 925-6208
philadelphia@gcssvc.com

GCS SERVICE INC. #44
4400 LEWIS ROAD
SUITE E
HARRISBURG, PA 17111
(717) 564-3282
800-367-3225
FAX: (717) 564-9286
harrisburg@gcssvc.com

GCS SERVICE INC. #48
210 VISTA PARK DRIVE
PITTSBURGH, PA 15205
(412) 787-1970
800-738-1221
FAX: (412) 787-5005
pittsburgh@gcssvc.com

K & D PARTS AND SERVICE CO.
1833-41 N CAMERON STREET
HARRISBURG, PA 17103
(717) 236-9039
800-932-0503
FAX: (717) 238-4367
kdparts-service@paonline.com

RHODE ISLAND:

GCS SERVICE INC. #09
1002 WATERMAN AVE.
EAST PROVIDENCE, RI 02914
(401) 434-6803
800-462-6012
FAX: (401) 438-9400
providence@gcssvc.com

SOUTH CAROLINA:

WHALEY FOODSERVICE REPAIRS
I 26&US1
P.O. BOX 4023
WEST COLUMBIA, SC 29170
(803) 791-4420
800-877-2662
FAX: (803) 794-4630
info@whaleyfoodservice.com

WHALEY FOODSERVICE REPAIRS
748 CONGAREE ROAD
GREENVILLE, SC 29607
(864) 234-7011
800-494-2539
FAX: (864) 234-6662
info@whaleyfoodservice.com

WHALEY FOODSERVICE REPAIRS
1406-C COMMERCE PL.
MYRTLE BEACH, SC 29577
(843) 626-1866
FAX: (843) 626-2632
info@whaleyfoodservice.com

WHALEY FOODSERVICE REPAIRS
4740-A FRANCHISE STREET
N. CHARLESTON, SC 29418
(843) 760-2110
FAX: (843) 760-2255
info@whaleyfoodservice.com

SOUTH DAKOTA:

GCS SERVICE INC.
2857 LOUISIANA AVENUE N.
MINNEAPOLIS, MN 55427
(612) 546-4221
800-345-4221
FAX: (612) 546-4286
minneapolis@gcssvc.com

TENNESSEE:

COMMERCIAL PARTS & SVC.
3717 CHERRY ROAD
MEMPHIS, TN 38118
(901) 366-4587
800-262-9155
FAX: (901) 366-4588

COMMERCIAL PARTS & SVC.
748 FESSLERS LANE
NASHVILLE, TN 37210
(615) 244-8050
800-831-7174
FAX: (615) 244-8885
alesco1@aol.com

COMMERCIAL APPLIANCE SVC.
919 8TH AVENUE SOUTH
NASHVILLE, TN 37203
(615) 254-0906
800-476-0906
FAX: (615) 254-0919
casnash@aol.com

TEXAS:

ARMSTRONG REPAIR CENTER
5110 GLENMOUNT DRIVE
HOUSTON, TX 77081
(713) 666-7100
800-392-5325
FAX: (713) 661-0520
gm@armstrongrepair.com

COMMERCIAL KITCHEN REPAIR CO.
1377 N BRAZOS
P.O BOX 831128
SAN ANTONIO, TX 78207
(210) 735-2811
800-292-2120
FAX: (210) 735-7421
brock@commercialkitchen.com

GCS SERVICE INC. #90
10850 SANDEN DRIVE
DALLAS, TX 75238-5325
(972) 484-2954
800-442-5026
FAX: (972) 484-2531
dallas@gcssvc.com

GCS SERVICE INC. #88
8150 WESTPARK
HOUSTON, TX 77063
(713)785-9187
800-868-6957
FAX: (713) 785-3979
houston@gcssvc.com

STOVE PARTS SUPPLY CO.
2120 SOLANA STREET
FORT WORTH, TX 76117
(817) 831-0381
800-433-1804
FAX: (817) 834-7754
bud@stoveparts.com

UTAH:

LA MONICA'S RESTAURANT EQMT. SVC.
6182 SOUTH STRATLER AVENUE
MURRAY, UT 84107
(801) 263-3221
800-527-2561
FAX: (801) 263-3229
lamonica81@aol.com

VERMONT:

AUTHORIZED APPLIANCE SERVICENTER OF VERMONT
74 RIVER STREET
RUTLAND, VT 05701
(802) 775-5588
800-874-1080
FAX: (802) 775-9593
aasc1@together.net

NORTHERN PARTS & SVC.
4874 S. CATHERINE STREET
PLATTSBURGH, NY 12901
(518) 563-3200
800-634-5005
FAX: (800) 782-5424
info@northernparts.com

GCS SERVICE INC. #09
180 SECOND STREET
CHELSEA, MA 02150
(617)889-9393
800-225-1155
FAX: (617) 889-1222
boston@gcssvc.com

JACKSON MAINTENANCE & REPAIR CENTERS

VIRGINIA:

DAUBERS, INC.
7645 DYNATECH COURT
SPINGFIELD, VA 22153
(703) 866-3600
800-554-7788
FAX: (703) 866-4071
daubers@aol.com

GCS SERVICE INC. #07
2660 PITTMAN DRIVE
SILVER SPRING, MD 20910
(301) 585-7550(DC)
(410) 792-0388(BALT)
800-638-7278
FAX: (301)495-4410
dc_baltimore@gcssvc.com

GCS SERVICE INC. #18
2421 GRENOBLE RD.
RICHMOND, VA 23294
(804) 672-1700
800-899-5949
FAX: (804) 672-2888
richmond@gcssvc.com

GCS SERVICE INC. #18
5760 NORTHAMPTON BLVD. STE 106
VIRGINIA BEACH, VA 23455
(757) 464-3500
800-476-4278
FAX: (757) 464-4106
virginia_beach@gcssvc.com

WASHINGTON:

GCS SERVICE INC.
6114 SIXTH AVENUE SOUTH
SEATTLE, WA 98108
(206) 763-0353
800-211-4274
FAX: (206) 763-5943

RESTAURANT APPLIANCE SERVICE
7219 ROOSEVELT WAY, NE
SEATTLE, WA 98115
(206) 524-8200
800-433-9390
FAX: (206) 525-2890
info@restappl.com

WEST VIRGINIA:

AFS-AUTHORIZED FACTORY SVC INC.
RT.-1 BOX 288
S. CHARLESTON, WV 25312
(304) 344-8225
800-654-4606
FAX: (304) 344-8248

WISCONSIN:

APPLIANCE SERVICE CENTER, INC.
2439 ATWOOD AVE
MADISON, WI 53704
(608) 246-3160
800-236-7440
FAX: (608) 246-2721
ascmad@execpc.com

APPLIANCE SERVICE CENTER, INC.
6843 W. BELOIT RD.
WEST ALLIS, WI 53219
(414) 543-6460
800-236-6460
FAX: (414) 543-6480
ascmil@execpc.com

APPLIANCE SERVICE CENTER
786 MORRIS AVE
GREEN BAY, WI 54304
(920) 496-9993
800-236-0871
FAX: (920) 496-9927
ascfox@execpc.com

WYOMING:

METRO APPLIANCE SERVICE
1640 S BROADWAY
DENVER, CO 80210
(303) 778-1126
800-525-3532
FAX: (303) 778-0268
metroappls@aol.com

INTERNATIONAL

GLOBAL PARTS AND SUPPLY
7758 NW 72ND ST
MIAMI, FL 33166
(305) 885-6353

H.D. SHELDON AND CO
19 UNION SQUARE, WEST
NEW YORK, NY 10003
(212) 627-1759
(212) 924-6920

CANADA

THR GARLAND GROUP
1177 KAMATO ROAD
MISSISSAUGA, ONTARIO L4W 1X4
(905) 206-8380
SALES
(905) 624-1419
FAX: (905) 624-1851
SERVICE
800-427-6668
FAX: 800-361-7745

Revised April 23, 2003

IMPORTANT INFORMATION DATA SHEET

Model: _____

Serial No.: _____

Installation Date: _____

Service Rep. Name: _____

Phone No.: _____

Notes: _____